


## Humidifier tank

**Figure 60-1:**  
**LTS tank replacement parts**



## Humidifier tank

**Table 61-1:  
LTS tank replacement parts**


| Number in drawing | Description                     | Part number    |
|-------------------|---------------------------------|----------------|
| 1                 | Tank, LTS                       | *              |
| 2                 | Cover, LTS-25                   | 165341-001     |
|                   | Cover, LTS-100                  | 165341-003     |
|                   | Cover, LTS-400                  | 165341-004     |
| 3                 | Cover gasket, LTS-25            | 160692-001     |
|                   | Cover gasket, LTS-100           | 160692-003     |
|                   | Cover gasket, LTS-400           | 160692-004     |
| 4                 | Heat exchanger, LTS             | *              |
| 5                 | Cleanout plate, LTS-25          | 165481-001     |
|                   | Cleanout plate, LTS-100         | 165481-002     |
|                   | Cleanout plate, LTS-400         | 165481-003     |
| 6                 | Cleanout plate gasket, LTS-25   | 308015-001     |
|                   | Cleanout plate gasket, LTS-100  | 308015-002     |
|                   | Cleanout plate gasket, LTS-400  | 308015-003     |
| 7                 | Fill assembly                   | *              |
| 8                 | Float fill assembly, LTS-25/100 | 505315         |
|                   | Float fill assembly, LTS-400    | 505305         |
| 9                 | Drain assembly                  | *              |
| 10                | Temperature sensor assembly     | 405760         |
| 11                | Probe assembly                  | 406303-008     |
| 12                | Probe gasket                    | 309350-004     |
| 13                | Probe plate, DI water           | 120370-020     |
| 14                | Probe weld, standard water      | 165301         |
| 15                | Probe plate/weld gasket         | 308416-001     |
| 16                | Heat exchanger gasket           | 308220         |
| 17                | Heat exchanger mounting plate   | 164581-001     |
| 18                | Junction box                    | 407134-005/006 |
| 19                | Condensate return plug          | 250192-075     |

**Note:**

\* Contact your local representative with your model number when ordering this part. Components may in be different locations than shown in drawing.

## Control cabinet

**Figure 62-1:**  
**Control cabinet replacement parts**



**Note:**  
Components may in be different locations than shown in drawing.

## Control cabinet

**Table 63-1:**  
**Control cabinet replacement parts**

| Number in drawing | Description                           | Part number        |
|-------------------|---------------------------------------|--------------------|
| 1                 | Control cabinet, 12" x 12"            | 407100-003         |
| 2                 | Subpanel, LTS                         | 165720-002         |
| 3                 | Control board, Vapor-logic3           | 408632             |
|                   | Control board, LW417                  | 408490-001         |
| 4                 | Transformer, 120V to 24V              | 408965-001         |
| 5                 | Terminal block                        | 408252-001         |
| 6                 | Ground terminal                       | 408252-010         |
| 7                 | Terminal jumper                       | 408252-009         |
| 8                 | Area-type time delay relay            | 407900-010/016/018 |
| 9                 | DIN-rail end cap                      | 408252-006         |
| 10                | Terminal spacer                       | 408252-005         |
| 11                | DIN-rail, 6.5" (165 mm)               | 167765-006         |
| 12                | Ground lug                            | 409250-003         |
| 13                | P-E switch                            | 408100             |
| 14                | Interlock switch                      | 408470             |
| 15                | Interlock switch bracket              | 165614             |
| 16                | Vapor-logic3 keypad                   | 408490-002         |
| 17                | Vapor-logic3 keypad cable, 5' (1.5 m) | 408490-009         |

# Outdoor Enclosure replacement parts

Figure 59-1:  
Outdoor Enclosure replacement parts

The diagram shows a side view of a rectangular outdoor enclosure. Numbered callouts point to the following parts: 1 points to a heater strip on the upper right interior wall; 2 points to a heater strip on the lower left interior wall; 3 points to a cooling fan on the right exterior wall; 4 points to gaskets on the top and bottom door frames; 5, 6, and 7 are grouped together at the top right, pointing to high limit, low limit, and heater stats respectively; 8 points to a fan stat on the right exterior wall near the bottom.

**Note:**  
For humidifier replacement parts, refer to your humidifier's installation, operation and maintenance manual.

| Table 59-1:<br>Outdoor Enclosure replacement parts |                      |             |
|----------------------------------------------------|----------------------|-------------|
| Number in drawing                                  | Description          | Part number |
| 1                                                  | 500W strip heater    | 405800-052  |
| 2                                                  | 1100W strip heater   | 405800-053  |
| 3                                                  | Cooling fan          | 405800-068  |
| 4                                                  | Gasket, door or roof | 308005-010* |
| 5                                                  | Stat, high limit     | 405800-065  |
| 6                                                  | Stat, low limit      | 405800-066  |
| 7                                                  | Stat, heater         | 405800-066  |
| 8                                                  | Stat, fan            | 405800-067  |
| * Specify quantity in feet                         |                      |             |